






INSTALLATION MANUAL

KARIZMA luce









Juno LENS XS



AC220-240V | 50/60Hz | IP20 | Die cast



Do not operate with power supply connected.

1  To mount the track adaptor into the track system, first check that the selector knob A is at OFF position and the adaptor lock B is disengaged.	2  When installing the adaptor into the track, ensure that it is orientated correctly.	3  Rotate adaptor lock B clockwise to connect the adaptor to the neutral circuit.
4  Rotate selector knob A to the position of desired circuit.	4a  Circuit 1: Rotate the knob A clockwise from the starting position OFF, to connect circuit 1.	4b  Circuit 2: Rotate the knob A counter-clockwise from the starting position OFF, to connect circuit 2.
4c  Circuit 1: Rotate the knob A clockwise from the starting position OFF, to connect circuit 3.	5  355° 90°	

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.